

INSTRUCTIONS

MINI ADHESIVE D RING

CODE ⇒101481

NLG ID

Scan the orange tags on compatible NLG products to access detailed product info, certification and installation videos.

NOTE

Make sure the surfaces are clean and free from grease. Different surface types can affect

adhesion. Test before use.

01



Remove the white side of the 3M pad and attach to the underside of the Mini D Ring. Push firmly to secure.

02



Remove the red side of the 3M pad and attach the Mini D Ring to a flat surface on the tool. (DO NOT attach to battery compartment doors, as these can come off). Push firmly to secure.

03



Smooth the pad down onto the tool firmly and allow 24 hours to fully bond.

04

Test the tether point before putting the tool into use.